

CAUTION

Prior to installing, the instructions provided herein should be completely reviewed and understood before operating or repairing this equipment. All CAUTION and WARNING notes must be strictly observed to prevent personal injury or equipment damage.

Description

Models LD, LP and LB are designed to be operated by a float/lever trunnion assembly for use in liquid dump control applications. The valves have a single port body and are Lever Operated.

The LD is balanced by a diaphragm, while the models LP and LB are balanced by a piston.


The models LD, LP and LB feature quick-opening trim, but because of their direct mechanical link with the liquid level, normal action is a throttling mode. The valve is balanced allowing it to function smoothly and close completely regardless of the pressure differential from upstream to downstream. The valve's large opening provides high flowing capacity.

A name tag is attached to each valve. The name tag lists the serial number, model number, and pressure rating. An additional tag is installed to indicate any special trim options, should they be required.

Installation

Before installing the mechanical oil valve and trunnion assembly, inspect it for shipment damage and for foreign material that may have collected during shipment. Inspect the openings in the valve and clean the pipe lines to remove scale, chips and debris. For flanged bodies, remove the masking sticker from the raised face of each end connection.

1. Install the valve with the arrow on the body pointing in the direction of flow. The arrow signifies that the device will operate properly in the direction of flow indicated and will not necessarily prevent flow in the opposite direction.
2. Install the valve using good piping practices. For flanged bodies use a suitable gasket between the body and the pipeline flanges.
3. The flanged valve bodies are rated ANSI class 150. Do not install the valve in a system where the working pressure can exceed ANSI class ratings.
4. Verify all pressure connections are tight before pressurizing the system.



CAUTION

When ordered, the lever operated liquid dump valves and trunnion assembly configuration and construction materials were selected to meet specific pressure, temperature, pressure drop and fluid conditions. Since some body/trim material combinations are limited in their pressure drop and temperature ranges, do not subject the lever operated liquid dump valves and trunnion assembly to any other conditions without first contacting the Kimray Inc, sales office or a sales / applications representative

QUICK START GUIDE

Start-up and Test

With the installation completed and appropriate relief and check valves installed and set, slowly open the upstream and downstream shutoff valves. In order to test the function of the valve, allow only a small amount of upstream pressure to flow through the upstream shutoff valve. Check for proper valve operation by cycling the actuator arm several times. Then watch as the vessel fills to be sure the float and linkage are operating properly.

Maintenance

Maintenance should be performed on a regular basis. An initial inspection interval of 12 months is recommended. Depending on the service conditions of the valve, the inspection interval may be decreased or increased.

The valve can be repaired without removing the body from the piping.

Only use genuine Kimray replacement parts.

Repair kits and detailed repair instructions are available for each valve.

Visit www.kimray.com or contact your Kimray authorized distributor for additional product information and / or literature.

Inspection Schedule	
*Valve Seat	Inspect every 6 months under normal service and conditions. Under severe service conditions such as sand, corrosion, salt, or high pressure drop, inspect regularly until a predictable pattern can be established.
Seals	Should be replaced as needed. Check for cracks, swelling or if the seals feel hard. Replace as needed.
Body	Under normal conditions, the body will last years. Severe conditions will require inspection more frequently. The body should be inspected every time valve trim is inspected.
* Under severe operating conditions this maintenance schedule will not be adequate and a more frequent time schedule may be required.	

Trouble Shooting		
Problem	Possible Cause(s)	Possible Solution
Fluid leaking from bonnet through stuffing box	Shaft packing or the shaft itself is worn.	Replace packing. / Check for shaft wear.
Fluid leaking from body / bonnet joint.	Screws attaching bonnet to body are loose.	Tighten bolts.
	Seal between body and actuator is worn or damaged.	Replace seal.
Excessive trim leakage with the valve closed.	Debris is interfering with seat contact.	Clean seat and any obstructions.
	Insufficient shut-off force from the trunnion lever.	Increase force by moving ball joints as detailed in Diagram 1.
	Seat surfaces are worn or damaged.	Clean surfaces and / or replace.
Valve stem movement is sticky or jerks.	Valve stem is bent or misaligned.	Replace either stem, cage or cylinder.
Valve not fully closing or fully opening	Undersized float Undersized float rod	Install larger float (see float selection guide) Use longer float rod

WARNING

Before beginning installation:

- Read and follow instructions.
- Make sure the valve cannot operate during installation.

Do not exceed the maximum supply pressure specified on the valve nameplate.

Never tighten any fitting or the main connections to the valve while there is pressure on the line.

WARNING

Before any service, be certain that the valve is fully isolated and that all pressure upstream and downstream has been relieved. Use bypass valves or fully shut off the process.

Be sure that any operating or instrument gas lines have been disconnected.

Never stand directly in front of or over a valve when the system is pressurized. The valve could suddenly open, blowing debris into the person's face and eyes.

WARNING

A leaking valve is an indication that service is required. Failure to take valve out of service immediately may cause a hazardous condition.

NOTE

If conditions indicate the possibility of backward flow you may wish to install check valves. Never assume that a check valve is fully blocking the downstream line.

For questions or comments, contact your local Kimray authorized distributor, or visit www.kimray.com.

Kimray Inc.
52 NW 42nd Street
Oklahoma City, OK 73118

Customer Service: 405.525.6601 | service@kimray.com

Product/Tech Support: 405.525.4264 | prodtechsupport@kimray.com

All Pictures shown are for illustration purpose only. Actual product may vary due to product enhancement.
‡ Configuration of the Mechanical Level Control is a trademark of Kimray, Inc.